
1125 Series Manual and Electric Hose Reels

Parts Lists and Set-Up Instructions

If your hose reel installation requires drilling into the tank, the tank interior **MUST** be vacuumed and flushed **prior to operation.** Failure to do so will cause clogging of the system's filters and screens.



P. O. Box 3107 • Visalia, CA. 93278-2107 Tel: 559-SDI-5555 • Fax: 559-SDI-5591 email: sales@sprayingdevices.com www.sprayingdevices.com



Mounting Instructions:


- 1. Place the Hose Reel in the desired location on the tank and mark the hole locations.
- 2. Drill 3/4" holes in tank to match the Hose Reel.
- 3. Insert the well nut through each hole.
- 4. After drilling holes in tank, the tank interior **must** be vacuumed and flushed *prior to operation*. Failure to do so will cause clogging of the system's filters and screens.
- 5. Line up the holes in the Hose Reel base with the holes you have drilled in the tank and bolt into place.
- 6. Install additional plumbing and connect hose to Hose Reel.
- 7. Install the Gun Holder in a convenient location.


SDI Hose Reel Mounting Instructions - 200 Gallon

1

]	Item No.	Part No.	Description	Qty					
	1	11-401	Gun Holder	1					
	2	55-212	Male Hose Coupling 1/2"	1					
	3	24-203	Hose Clamp Bandit #JS2	03 2	SPRAYING DEVICES, INC.				
	4	55-211	Female House Coupling	1/2" 1					
	5	55-106	Adapter 3/4 MPT x 3/4" I	MGHT 1					
	6	60-324	Ball Valve 3/4"	1					
	7	51-501SS	Close Nipple 3/4" SST	2					
	8	50-520SS	Tee 3/4" SST	1					
	9	81-500	Feed Hose, Per Foot	Specify					
	10	50-510SS	Street Elbow 3/4" SST	1					
	11	55-108	Adapter 3/4 MPT x 3/4" I	FGHT 1					
	12	32-504	Bolt 3/8 x 1-1/4" SST	4	-				
	13	42-706	Fender Washer 3/8"	4	(13)				
	14	41-450	Well Nut 3/8"	. 4					
				(12)-	~				
				\bigcirc					
				(11)					
				\sim					
				(2)					
Man	ntin a Tract			()					
NIOU	nting Inst	ructions:	(5					
1	Dlaga th	e Hose Reel i		\prec (9)	W				
1.				$\langle \setminus \setminus \frown$					
			nd mark the hole						
2	location								
2.			k to match the (10)						
2	Hose Re			G					
3.			bugh each hole.						
4.	After drilling holes in tank, the tank								
	interior must be vacuumed and flushed <i>prior to operation</i> . Failure to do so will								
	and scre		system's filters	\langle / \rangle					
5				\sim					
5.	-	the holes in the holes in the	1 11	\checkmark /)					
		th the holes yo n the tank and	1 11						
		ii the tank and			Y' K				
6	place.	dditional -1	abing and						
6.		dditional plun hose to Hose	-						
7									
7.		he Gun Holde	1 III ä						
	convent	ent location.							
		haon II	Deel						
		bsen Hose l			*				
		ng Instructi							
8	89895/88	89896 Hose	Reel	2					
	Spraying Devices, Inc., P. O. Box 3107, Visalia, CA. 93278•Tel:559-SDI-5555•Fax:559-SDI-5591								


Spraying Devices, Inc., P. O. Box 3107, Visalia, CA. 93278•Tel:559-SDI-5555•Fax:559-SDI-5591 email: sales@sprayingdevices.com





Manual Hose Reel - 1125 Series

Item Number	Part Number	Description	Qty
1	59-507	Frame 1125-4-100	1
1	59-508	Frame 1125-4-200	1
1	59-509	Frame 1125-4-325	1
2 3	59-301	Disc SWV Side	1
	59-300	Disc Crank Side	1
4	59-499	Center Drum 1125-4-100	1
4	59-500	Center Drum 1125-4-200	1
4	59-501	Center Drum 1125-4-325	1
5	59-504	Axle Assembly 1125-4-100	1
5	59-505	Axle Assembly 1125-4-200	1
5	59-506	Axle Assembly 1125-4-325	1
6	59-205	Swivel	1
7	59-228	Top Pillow Block Mounting	2
8	59-229	Bottom Pillow Block Mounting	2
9	59-230	Bearing	2
10	59-232	Retaining Ring	4
11	59-512	Lock Pin Assembly	1
12	59-251	Flatwasher 5/16"	2
13	59-236	Bolt 5/16-18 x 3/4" Long	10
14	59-237	Locking Nut 5/16"	2
15	59-511	Trim, Per Inch	Specify
16	59-240	Lockwasher 5/16"	8
17	59-241	Flatwasher 3/8"	4
18	59-242	Bolt 3/8-16 x 1" Long	4
19	59-243	Locking Nut 3/8"	4
20	59-513	Drag Brake	1
21	59-256	Hand Crank	1



Electric Hose Reel - 1125 Series

Item	Part		
Number	Number	Description	Qty
1	59-520	Frame 1125-4-100E	1
1	59-521	Frame 1125-4-200E	1
1	59-522	Frame 1125-4-325E	1
2	59-302	Disc W/Gear	1
3	59-300	Disc Crank Side	1
4	59-499	Center Drum 1125-4-100E	1
4	59-500	Center Drum 1125-4-200E	1
4	59-501	Center Drum 1125-4-325E	1
5	59-504	Axle Assembly 1125-4-100E	1
5	59-505	Axle Assembly 1125-4-200E	1
5	59-506	Axle Assembly 1125-4-325E	1
6	59-205	Swivel	1
7	59-228	Top Pillow Block Mounting	2
8	59-229	Bottom Pillow Block Mounting	2
9	59-230	Bearing	2
10	59-232	Retaining Ring	4
11	59-510	Сар	1
12	59-236	Bolt 5/16-18 x 3/4" Long	8
13	59-511	Trim, Per Inch	Specify
15	59-240	Lockwasher 5/16"	8
16	59-241	Flatwasher 3/8"	4
17	59-242	Bolt 3/8-16 x 1" Long	4
18	59-243	Locking Nut 3/8"	4
19	59-247	Motor	1
20	59-305	Pinion	1
21	59-400	Pinion Key/Not Illustrated	1
			1