




**SDI Diaphragm Pump
Model 78-0026**

PI02/16jh

SDI Diaphragm Pump, Model 78-0026

Item Number	Part Number	Description	Qty.
1	78-033	Discharge Flange	1
2	78-034	Bolt	6
3	78-037	Safety Valve Assembly	1
9	78-0335	O-ring	1
10	78-0336	O-ring	1
11	78-0331	Plastic Gasket	1
12	78-032	O-ring	1
13	78-031	O-ring	1
14	78-030	O-ring	1
15	78-029	Oil Seal	1
16	78-034	Bolt	1
17	78-073	Valve Cover	2
18	78-333	Flat Washer	2
19	78-409	Nut	2
20	78-442	O-ring	1
21	78-065	Air Valve	1
22	78-064	Gasket	2
23	78-407	End Cap	1
24	*78-406	O-ring	1
25	*78-405	O-ring	1
26	*78-404	Damper	1
27	78-403	Body	1
28	78-402	Pulsation Damper Cap	1
29	78-401	Pulsation Damper	1
30	78-417	Hose Barb Elbow	1
31	78-418	Nut	1
32		O-ring	1
33	78-420	Adapter	1
34	*78-414	O-ring	1
35	48-421	Valve Chamber Manifold	2
36	78-429	Pump Crank Case	1
37	78-430	Ball Bearing	1
38	78-026	Connecting Rod Ring	2
39	78-025	Snap Ring	1
40	78-024	Ball Bearing	1
41	78-853	O-ring	1
42	78-427	Oil Reservoir	1
43	78-426	O-ring	1
44	78-425	Cap	1
46	78-432	Shaft	1
47	78-433	O-ring	1
48	78-434	Spacer Ring	1
49	78-435	Seal	1
50	78-021	Snap Ring	1
51	78-046	Plug	1
52	78-431	O-ring	1
53	*78-805	O-ring	8
54	78-034	Bolt	7
55	78-416	Valve Cover	2
56	78-414	O-ring	8

SDI Diaphragm Pump, Model 78-0026

Item Number	Part Number	Description	Qty.
57	*78-076	Valve Assembly	8
58	**	Suction/Delivery Valve Cage	8
59	78-292	Spring	8
60	**	Suction/Delivery Valve	8
61	**	Suction/Delivery Valve Seat	8
62	**	O-ring	8
	**	<i>Available with 78-076 only</i>	
63	78-084	Flat Washer	8
64	78-424	Bolt	16
65	78-422	Discharge Head	2
67	78-423	Mount Plate	2
68	78-051	Screw	4
69	78-145	Disc	4
*70	78-440	Diaphragm/Buna	4
70	78-440V	Optional Diaphragm/Viton	4
71	78-439	Piston Sleeve	4
72	78-438	Piston Ring	4
73	78-437	Piston	4
74	78-436	Connecting Rod Assembly	1
75&76	78-529	Pipe Plug	2
77	78-048	Snap Ring	8
78	78-049	Wrist Pin	4
	78-094	Repair Kit— <i>Includes item numbers 24, 25, 26, 34, 53, 57, and 70.</i>	
			2/18/2016