





**SDI PUMP, MODEL NO.
 78-0028**

PUMP, MODEL 78-0028 (Formerly 78-010 & 78-100)

Item Number	Part Number	Description	Qty
1	78-101	Crankcase	1
2	78-102	Valve Chamber	3
3	78-103	Accumulator Body	1
4	78-061	Accumulator Support	1
5	78-062	Accumulator Diaphragm	1
6	78-106	Accumulator Cover	1
7	78-084	Washer	6
8	78-108	Hex Nut	4
9	78-065	Air Valve	1
10	78-064	Gasket	2
11	78-301	Lock Pin	1
12	78-112	Clamping Collar	3
13	78-113	Socket Head Capscrew	3
14	78-114	Cylinder Sleeve	3
15	78-311	Oil Filler Tube	1
16	78-310	Oil Filler Cover	1
17	78-312	Hex Nut	2
18	78-309	O-Ring	1
19	78-119	Suction Manifold	2
20	78-120	Suction Manifold Inlet	1
21	78-805	O-Ring	3
22	78-815	O-Ring	1
23	78-038	Retaining Nut	1
24	78-124	Elbow Fitting	1
25	78-125	Check Valve Assembly	6
26	78-126	O-Ring	6
27	NPN	Refer to Check Valve Assembly	
28	NPN	Refer to Check Valve Assembly	
29	NPN	Refer to Check Valve Assembly	
30	NPN	Refer to Check Valve Assembly	
31	78-131	Socket Head Capscrew	12
32	78-132	Crankshaft (1-3/16" Round)	1
32	78-132A	Crankshaft (1-3/8" Six-Spline)	1
33	78-133	Retaining Ring	2
34	78-134	Spacer Washer	2
35	78-135	Ball Bearing (For Round Shaft)	1
35	78-135A	Ball Bearing (For Splined Shaft)	1
36	78-136	Oil Seal (For Round Shaft)	1
36	78-136A	Oil Seal (For Splined Shaft)	1
37	78-137	Roller Bearing	1

PUMP, MODEL 78-0028 (Formerly 78-010 & 78-100)

Item Number	Part Number	Description	Qty
38	78-138	Spacer Washer	1
39	78-139	Roller Bearing	1
40	78-140	Connecting Rods, Set of 3	1 Set
41	78-141	Piston	3
42	78-142	Wrist Pin	3
43	78-143	Snap Ring	6
44	78-144	Diaphragm, Buna-N	3
45	78-145	Retainer Disc	3
46	78-146	Shoulder Screw	3
47	78-147	Shaft Key	1
48	78-148	Pump Mount	2
49	78-149	O-Ring	2
50	78-150	Adapter Fitting 3/4" MPT	1
	78-155KIT	Repair Kit - Includes the following:	
	78-062	Accumulator Diaphragm	1
	78-310	Oil Filler Cover	1
	78-805	O-Ring	3
	78-815	O-Ring	1
	78-125	Check Valve Assembly	6
	78-144	Diaphragm, Buna-N	3