





**SDI Pump, Model
No. 78-0057**

PI44/496

MODEL 78-0057



PI 44/496

Pump, Model 78-0057

Item Number	Part Number	Description	Qty
1	78-601	Bolt	12
2	78-602	Cover	1
3	78-603	Gasket	1
4	78-604	Seal	1
5	78-605	Body	1
6	78-606	Accumulator Assembly	1
7	78-607	Accumulator Cover	1
8	78-608	Diaphragm	1
9	78-609	Body	1
10	78-610	O-Ring	1
11	78-611	Oil Sight Glass	1
12	78-612	O-Ring	1
13	78-613	Flange	1
14	78-428	O-Ring	2
15	78-614	Adapter	1
16	78-615	Bearing	1
17	78-616	Washer	1
18	78-617	Spacer	2
19	78-539	Bearing	1
20	78-618	Crankshaft	1
21	78-619	Washer	1
22	78-620	Bearing	1
23	78-621	O-Ring	1
24	78-622	Seal	1
25	78-623	Flange	1
26	78-624	Pump Base	2
27	78-526	Bolt	6
28	78-625	Lockwasher	6
29	78-626	Washer	1
30	78-627	Plug	1
31	78-628	Sleeve	5
32	78-563	Diaphragm	5
33	78-564	Bolt	5
34	78-565	Retainer	5
35	78-629	Head	5

Pump, Model 78-0057

Item Number	Part Number	Description	Qty
36	78-630	Connecting Rod	5
37	78-560	Snap Ring	10
38	78-631	Piston	5
39	78-562	Piston Ring	5
40	78-559	Wrist Pin	5
41	78-851	Nut	1
42	78-852	Hose Barb	1
43	78-853	O-Ring	1
44	78-854	Adapter	1
45	78-855	O-Ring	2
46	78-856	Valve Seat	1
47	78-857	Body	1
48	78-810	Screw	1
49	78-859	Valves	1
50	78-860	Diaphragm	1
51	78-861	Body	1
52	78-862	Screw	1
53	78-863	Lever	1
54	78-864	Pin	2
55	78-865	Rod	1
56	78-866	Clip	1
57	78-867	Spring	1
58	78-868	Cap	1
59	78-850	Pressure Regulator	1
60	78-869	Compensator	1
61	78-870	Spring	1
62	78-871	Special Screw	1
63	78-635	Suction Fitting	5
64	78-636	Suction Manifold	4
65	78-634	Cage	5
66	78-078	Spring	5
67	78-633	Check Valve Assembly	5
68	78-508	Disc	5
69	78-507	Seat	5
70	78-637	O-Ring	5

Pump, Model 78-0057

Item Number	Part Number	Description	Qty
71	78-349	O-Ring	3
72	78-638	Manifold	1
73	78-639	O-Ring	1
74	78-640	Nut	1
75	78-641	Elbow	1
76	78-528	Handle	1
77	78-566	Ball Valve	1
78	78-858	Nut	1
79	78-644	Gauge	1
80	78-645	Manifold	5
81	78-646	O-Ring	6
82	78-647	Manifold	1
83	78-648	Plug	1
84	78-521	Ball Valve	1
85	78-520	Gasket	1
86	78-517	Valve Assembly	1
87	78-519	Hose Barb	1
88	78-518	Nut	1
89	78-649	Hose Tail	1
90	78-650	Hose Barb	1
91	78-651	O-Ring	2
92	78-652	Hose Barb	1
93	78-653	Nut	1
94	78-642	Clamp	1
95	78-643	Screw	1